



NOTES:

1. MORTAR BED SUFFICIENT TO SECURE THE PANEL, INSTALL MORTAR IN LIGHT APPLICATIONS OF MEMBRANE ADHESIVE. LEAVE MIN. 6 IN. WIDE GAPS IN MORTAR AT MAX. 6 IN. O.C. TO FACILITATE DRAINAGE.
2. PAVERS OVER CONCRETE SAND OVER COMPACTED AGGREGATE SHOWN, ADDITIONAL SURFACINGS TYP. INCLUDE CONCRETE TOPPING, AGGREGATE, TILE OVER MORTAR BED OR TERRAZZO.
3. LAURENCO PMMA LIQUID FLASHING MEMBRANE MAY BE UTILIZED IN LIEU OF THE SHEET MEMBRANE FLASHING.