



LAURENCO  
WATERPROOFING

EXCELLENCE IN WATERPROOFING  
SINCE 1955 —

P.O. Box 599  
Mars, PA 16046  
Phone: 1-800-321-3337  
Fax: 1-800-543-3338

A Division of FBC Chemical Corp.

### **General Repair Guideline for Damaged PMMA:**

1. Expose and clean general area of the damaged PMMA of loose dirt, overburden and construction debris.
2. Remove any loose, damaged and de-laminated PMMA fragments.
3. Wipe clean, with acetone, an area around the damaged PMMA to accommodate a repair patch 2-inches around the location of the damaged PMMA.
4. Install new reinforced PMMA over the damage, in the cleaned area, according to the manufacturer's installation procedures.
5. Allow new PMMA repair application to cure before any covering with overburden or required water testing.